



GENERAL SAFETY GUIDELINES

WARNING! WATER = ELECTRIC SHOCK!

- **Keep dry and away from water**
- **Avoid tangle - Keep away from hair & jewelry**
- **Keep away from loose fabric**

Caution: This is a powerful massager. Consult your physician if you are pregnant, post-surgery, taking medication, breastfeeding, have cancer, or if you have a medical condition or medical issue, or are suffering from a recent car accident, whiplash or musculoskeletal trauma. Avoid massage near hair, eyes, mouth, front or side of neck.

Contraindications – DO NOT USE IF THESE CONDITIONS ARE PRESENT:

heart disease • heart issues • inflammation, infection, open wounds • bone fractures or breaks • muscle or tendon tears or ruptures • burns or skin problems • compartment syndrome, bursitis, gout • thrombosis/blood clot • artificial blood vessel implants • bleeding disorders/hemophilia • tumors/cancer cells • are taking anti coagulants • absolutely anything you're unsure of

Read manual, follow Safety Guidelines and consult your physician before using. Discontinue use immediately upon any discomfort or pain.

For use with 110-120V.

Information Disclaimer

The content contained here is provided “as is”, and without warranty of any kind, whether expressed or implied. Myobuddy Products, assumes no responsibility for information contained on this document and disclaims all liability in respect to such information.

This content is for general information purposes only and does not constitute legal, medical or health care advice or diagnosis. While Myobuddy Products, is committed to providing content that is accurate and true as of the date of writing, we give no assurances or warranty regarding the accuracy, timeliness, or applicability of any of the content. Reliance on any information appearing on this document is strictly at your own risk.

Users should not act, or refrain from acting on-the-basis of any content or information provided here without first seeking appropriate medical or health care advice on the health issue. Always seek out the advice of your physician with any questions or concerns you may have regarding your health or medical condition; if you think you may have a medical emergency, call your doctor or 911 immediately.



Myobuddy® Massager Pro 2 User Manual

Recovery | Relief | Mobility | Circulation | Fitness | Relaxation | Wellness

Myobuddy® Massager Pro 2 is a more powerful version of the massager that made us famous. It features frictional heat + vibration + percussion, providing a professional grade deep tissue massage that helps relieve aches, myofascial pain and stiffness. It's designed with 3 different levels of massage intensity for your body's changing needs. It feels amazing. Love it. Use it. Enjoy it every day!

Variable massage strength levels: For mild to relaxing to intense massages

Lightweight, slender design

12 foot long cord: Allows for ease of use around massage table, couch, bed, chairs

Multi-layered foam massage pad: Soft but firm with 3 layers. Wide surface area. Rounded edge.

1 - White massage pad cover & 1 blue massage pad cover

INDICATIONS AND SUGGESTED USES

Treat soreness, aches & pains & stiffness due to:

Stress • Chronic pain • muscle tension • circulatory challenges • scar tissue • accidents, incidents and mishaps • exercise • excessive sitting • postural dystonia • excessive standing

In harmony with:

Massage therapy • body work • personal training • physical therapy • yoga • chiropractic care • exercise routine • fascial therapy • myofascial release • relaxation/spa • home • work • gym • sport • leisure

Flat Massage Technique

Apply the spinning disk to massage your areas of need, whether it be for the relief of aches, pains and soreness, increasing circulation, reducing stiffness or more.

Massage for 30 seconds to 5 minutes. To generate more heat, adjust your unit to a higher intensity, add slight downward pressure on massage. See “Flat Technique” later in the guide.

Edge Massage Technique

For a more intense massage, apply the edge of the massage pad to your areas of need, whether it be for the relief of aches, pains and soreness, increasing circulation, reducing stiffness or more. Massage for 30 seconds to 5 minutes. For even more intensity add a little pressure and hold in place for up to 20 seconds, or continuously slide the edge of the massage pad. Remember to breathe deep and enjoy. See “Edge Technique” later in the guide.



Massage Pad Covers (bonnets)

Massage pad covers (also called bonnets) are used to cover the foam massage pad on your Myobuddy Massager. All bonnets are fully washable and reusable. Use them in the washer and dryer as needed. They are also very durable and long lasting. Not recommended for use directly on skin for people who may have sensitive skin.

White bonnet: For use over clothing (personal use) or over a sheet (professional use).

Blue bonnet: You may use the blue bonnet with or without lotion, oils, gels, aroma therapy, and topical applications. Apply directly to the bonnet in small amounts. You may even apply salts to help ex-foliate skin.




PUTTING ON THE BONNETS:



Try stretching your bonnet out first.



Then wrap it all the way around the massage pad, for a secure fit.



Make sure it fits tightly around the whole pad.

AIR BUBBLE:



To stop air bubbles from fanning out the bonnet...



...maintain contact with massage pad.

TURNING IT ON:

Press the power button once to start. Your massager will always start on low. To increase the intensity to medium, press the power button a second time. To increase the intensity to the highest level, press the power button a third time. Pressing the power button a fourth time will turn it off.





LOW: Low setting is a very mild and should be used only for light contact – do not apply much pressure when using it on low. Low is often used for tender spots, treating scar tissue, or just a light way to stimulate blood flow and loosen up. You may hold the massage pad flat on your body with very light contact, or use the edge of the massage pad for gentle percussive bounce.

MEDIUM: Medium setting provides a relaxing and soothing amount of vibration and percussion with some frictional heat (frictional heat will be more apparent on high). This setting is used for relaxing massages, increasing blood flow, easing soreness, aches and pains and much more. Try holding the massage pad flat against your body for a soothing massage. Then after a good warm up, turn the massage pad on an angle – so you're using the edge of the massage pad to provide a deeper penetrating massage.

HIGH: High is the most intense of all settings. Using the flat side of the massage pad on this level will generate a strong vibrational and percussive massage with soothing frictional heat. To increase frictional heat, add a little downward pressure towards the massage pad. Then, hold in one place to feel more heat. Move slowly to the areas of your liking with slight pressure to spread the warmth around. Then, after a good warm up, turn the massage pad on an angle – so you're using the edge of the massage pad to provide a deeper penetrating massage.

GRIP:



You may grip our massager around the base. It provides excellent control and ease of use for some users and allows you to massage with just one hand. However, some prefer to use our handle or a combination of base grip and handle. See which grip works best for you.

FLAT TECHNIQUE:



Using the massage pad flat on your body will provide a vibrational and percussive massage. Doing this on medium and high will generate soothing frictional heat. To increase frictional heat, turn to the highest level, add a little downward pressure towards the massage pad. Then, hold in one place to feel more heat. Move it slowly to the areas of your liking with slight pressure to spread the heat around.

EDGE TECHNIQUE:




For a deeper tissue massage that loosens up fascia and muscle more intensely, turn the massage pad on an angle – and use the edge of the pad. Doing this on high provides our most intense massage. You may benefit from using the flat technique to warm up your muscles right before starting the edge technique.



LENGTH OF TIME PER MASSAGE

The length of time for optimal massage may vary from situation to situation and person to person. In general, you can feel the benefits of a good massage in just 30 seconds and you can probably reach the entire body in about 5 minutes. However, some may wish to treat areas for as long as 3 to 5 minutes. You can use daily and multiple times a day. Discontinue use at the first sign of any pain.



Avoid tangle – keep away from hair and jewelry.



SOME FAQ'S

How does a Myobuddy® Massage help with workout recovery?

Post workout massage will keep the fascia from tightening, and push lactic acid and waste, all while oxygenating muscle cells and increasing circulation.

How does a Myobuddy® Massage help with mobility?

The percussive massage of the Myobuddy Massager Pro helps release tension and stiffness.

What are the benefits of using a Myobuddy® Massager daily?

Massaging your body every day can help with aches and pains, muscle soreness, mood, detoxification, muscle performance, stress relief and more.

Is it safe to use a Myobuddy® Massage on all areas of my body?

Most bodily areas respond very positively to Myobuddy massage. But be very careful, lightly treating the back and sides of the neck. Do not treat the front of the neck/throat. Do not use on veriscosities, tissue inflammation or healing injuries such as stitches and healing bones. Stay away from tumors, undiagnosed lumps and cysts. Do not use the Myobuddy Massager on your face or head. If you are uncertain about anything, consult your physician prior to use. For complete safety information read the entire safety guide.

Can I use lotions and massage oils with a Myobuddy® Massager?

Absolutely! In fact, the Myobuddy Massager takes a little lotion or oil (1.5 tsp) and spreads it very well. Use nutritive oils such as organic coconut oil, cacao butter or jajoba oil. Check out website for special Myobuddy blends. This is especially good after dry-brushing, as dry brushing is ex-foliating. We also recommend using aroma therapy oils on the blue pad.

Is it safe to use a Myobuddy® Massager on clothing and fabric?

Yes, the microfiber plush bonnets have some slip, allowing them to glide over most cloth without harm or bunching. Just be sure to keep the spinning disk away from loose, stringy cloth and jewelry. For complete safety information read the entire safety guide.

Do Myobuddy® Massagers cause itching?

No worries! Itching is common feeling with sudden increase in circulation. When the muscle cells and blood vessels dilate, stimulation of the nervous system may create an itching affect.



PRODUCT INTEGRITY AND WARRANTY

The buyer is automatically registered for a 1 year warranty when you make your purchase at Myobuddy.com or at our official Myobuddy® Massager storefront on Amazon. A standard 1-year manufacturer warranty covers mechanical failure. It does not cover failure due to using with improper electric voltage. This unit requires 110-120V. If you purchased from an authorized Myobuddy® reseller – you may register for your 1-year warranty by visiting www.myobuddy.com/warranty-registration. Note: if you purchased from a non-authorized reseller, Myobuddy® will not honor any warranty claims.

VIDEO INSTRUCTIONS

We have video demonstrations videos of our massager on all different parts of the body. Visit our website to view the instructional videos: www.myobuddy.com

CONTACT

For questions email us at: info@myobuddy.com

To call customer service dial: 844-696-2833

Visit our website at: www.myobuddy.com

© 2020 Myobuddy Massager. All rights reserved.